




teo

Leading  
the Light




## PCD-21P

Pockels Cell Driver with bell-shaped pulse

High-voltage bell-shaped pulses with nanosecond duration for controlling an electro-optical Q-switch in solid-state lasers.

## Features

- Low voltage (5 V) power supply;
- Built-in pulsed high-voltage source;
- Positive logical level trigger  $3 \div 8$  V;
- Additional output signal for HV-pulse amplitude measurement;
- Reduced electro-magnetic noise due to bipolar HV pulse relative to common ground;
- Output pulse amplitude adjustment by built-in potentiometer or by external signal;
- Ultra-compact design and light weight.




## Specifications

Output voltage amplitude <sup>1</sup>	2400 ÷ 3600 V
Output voltage pulse-to-pulse instability	1 %
Max pulse current	20 A
Max load capacitance	20 pF
HV pulse rise time <sup>2</sup>	1.0 ÷ 2.0 ns
HV pulse duration (factory-set) <sup>3</sup>	2 ÷ 4 ns
HV pulse fall time <sup>2</sup>	1.2 ÷ 2.2 ns
Max HV pulse repetition rate	2 kHz
Trigger voltage (input impedance is 470 Ohms)	3 ÷ 8 V (5V)
Output pulse delay from trigger pulse <sup>4</sup>	10 ÷ 15 ns
HV pulse jitter	< 0.1 ns
DC supply voltage	4.5 ÷ 5.5 V (5V)
DC supply current at maximum output pulse voltage:	
at a repetition rate of 1 kHz	300 mA
at a repetition rate of 2 kHz	450 mA
Operating temperature range	-40 ÷ +60 °C
Operations without failure	> 4 × 10 <sup>11</sup>
Dimensions	30 × 50 × 8 mm <sup>3</sup>
Mounting hole pattern (Ø 3.2 mm)	24 × 44 mm

1 is set from the built-in potentiometer or remotely.  
 2 depends on load capacitance and output voltage amplitude.  
 3 is set by manufacturer.  
 4 delay depends on the trigger pulse. The higher trigger amplitude the shorter delay.

# Connection Diagram



## Connector J1 (input) – DF13-6P-1.25H (Hirose)

- |  |   |
|--|---|
| <ul style="list-style-type: none"> <li>1 Pin 1 (red) Power supply + 5 V &amp; 500 mA;</li> <li>2 Pin 2 (black) Power supply GND;</li> <li>3 Pin 3 (yellow) Trigger input + (3 ÷ 8) V;<br/><math>R_{INPUT} = 470 \text{ Ohms}</math>;<br/>Rising edge &lt; 20 ns;<br/>Duration &gt; 20 ns;</li> </ul> | <ul style="list-style-type: none"> <li>4 Pin 4 (black) Trigger GND;</li> <li>5 Pin 5 (green) Output voltage measure signal;<br/>DC voltage scale 1:10000; <sup>Note 1</sup></li> <li>6 Pin 6 (black) Output voltage measure GND.</li> </ul> |
|--|---|


## Connector J2 (output) – SM02B-BHSS (JST)

- |  |   |
|--|---|
| <ul style="list-style-type: none"> <li>1 Pin 1 (HV red) Positive high voltage output;</li> </ul> | <ul style="list-style-type: none"> <li>2 Pin 2 (HV blue) Negative high voltage output.</li> </ul> |
|--|---|

## Note 1

Pin 5 and Pin 6 can be used for setting the amplitude of the output voltage pulse from -20 % to +2 % (from value set by potentiometer RV46).



If 0 V is set on Pin 5 from an external source, the pulse amplitude will be ~ 2 % higher than the set value. If 5 V is set on the Pin 5, the pulse amplitude will be lower by ~ 20 %. The input impedance of the Pin 5 is 45 kOhms.



# Waveforms of the transmitted light beam

Pulse voltage:  $V_{PULSE} = 3600\text{ V}$ ;

Pockels cell half wave voltage:  $V_{\lambda/2} = 3800\text{ V}$





Leading the light

[www.teo.technology](http://www.teo.technology)  
[info@teo.technology](mailto:info@teo.technology)

 [LinkedIn](#)

Copyright © 2016-2024, TEO Technology. All rights reserved.

All content of this datasheet, including texts, charts, artwork, logos, graphics, photographs, is the property of TEO Technology or its affiliates, and is protected by national and international copyright laws.

